


Pick/Place Error Diagram



NOTE: Essentially the same diagram applies also to pallet and slipsheet pick/place sequence except for the Signal GripSensor_OK IN#1606 is replaced by IN#1597 to 1600 depending on the selected dispenser.